

MANUAL TOP WIND TONGUE JACK UF# 49-954032 1000lb UF# 49-954033 2000lb UF# 49-954050 5000lb

Handle Assembly

- Place the bolt through the hole of the handle and the shaft of the Lead screw, Insert the Nylon-lock nut in the bolt, tighten the Nylon-lock nut.
- 2. Torque the nuts to 15-20 ft-lbs.

Installation Instructions

- 1. Place the Tongue jack into the hole of coupler.
- 2. Insert bolts: Three bolts (not included) through the each hole.
- 3. Make sure the bolts rest directly on top of the trailer tongue.
- 4. Tighten lock-washers and nuts to mounting bolts.
- 5. Nuts to be torqued to 15-20 ft-lbs.









